



Kindergeschirr Children's set

Design und Dekor ABC: Dorothee Hiller
ABC design and pattern: Dorothee Hiller

Dekor EISENBAHN: Werkse Entwurf
RAILWAY pattern: factory design

Dekor HAPPY KIDS: Julia Kűfner
HAPPY KIDS pattern: Julia Kűfner







Design und Dekor ABC:
ABC design and pattern:
Dorothee Hiller

Kindergeschirr Children's set

Design und Dekor ABC: Dorothee Hiller
ABC design and pattern: Dorothee Hiller

Dekor EISENBAHN: Werksentwurf
RAILWAY pattern: factory design

Dekor HAPPY KIDS: Julia Kűfner
HAPPY KIDS pattern: Julia Kűfner

Da macht das Tisch decken und Essen Spaß. Das Kindergeschirr von Walkűre verzaubert die Kleinen. Groű ist der Spaß beim Lernen. Die lustig purzelnden Reliefbuchstaben regen zum „Be-Greifen“ an. Dank unserer widerstandsfähigen Hartporzellanqualität halten die Teller, Schűsseln und Buchstabenbecher so manche „Attacke“ von Kinderhänden spielend aus. Die Spezialglasur bewahrt den Farben dauerhaft ihre Frische und Glanz – selbstverstándlich spűlmaschinenfest.

This turns table-laying and eating into fun. Walkűre's Children's tableware enchants the little ones. Learning is lots of fun. Kids want to know what the funny, tumbling raised letters mean. Our tough, hard porcelain makes it child's play for the cups, bowls and letter beakers to withstand even the roughest treatment from the kids. And with the special glaze, colours keep their freshness and shine – and of course they are dishwasher-safe.



Kindergeschirr – Dekor ABC
Children's set – ABC pattern



350 023
Teller flach
Dinner plate
23 cm Ø
645 g



350 021
Schüssel
Bowl
21 cm Ø
540 g



350 025
Becher blau
Mug blue
0,25 l
270 g



350 025
Becher rot
Mug red
0,25 l
270 g



350 025
Becher grün
Mug green
0,25 l
270 g



350 025
Becher gelb
Mug yellow
0,25 l
270 g

Kindergeschirr – Dekor EISENBAHN
Children's set – RAILWAY pattern



268 025
Becher
Mug
0,25 l
265 g



577 025
Trinkbecher
Mug
0,25 l
230 g



250 019
Teller flach
Dinner plate
19 cm Ø
355 g



250 024
Teller flach
Dinner plate
24 cm Ø
500 g



270 017
Schüssel
Bowl
17 cm Ø
320 g

Kindergeschirr – Dekor HAPPY KIDS
Children's set – HAPPY KIDS pattern



296 030
Becher
Mug
0,3 l
320 g



268 025
Becher
Mug
0,25 l
265 g



556 020
Teller flach
Dinner plate
20 cm Ø
400 g



556 020
Teller flach
Dinner plate
20 cm Ø
400 g



270 017
Schüssel
Bowl
17 cm Ø
320 g



556 923
Teller tief
Soup dish
23 cm Ø
625 g



556 023
Teller flach
Dinner plate
23 cm Ø
550 g